

Spare parts list valid for the following types:

No longer

<Version ID>

series since:

COMPR. - F3

Item no. : 12015<001>

COMPR. - FX3

Item no. : 12085<001>

Pos.	Part no.	Description	Quantity	QU
1	04012	COMPRESSOR CASING	1	Pc
2	04035	BASE PLATE	1	Pc
3	05045	BASE PLATE GASKET	1	Pc
4	05421	HEX. HEAD SCREW M8X25	14	Pc
5	05028	LOWER VALVE PLATE GASKET ø55	1	Pc
6	07149	VALVE PLATE, COMPLETE	1	Pc
ONLY AVAIL.AS COM.AS.KIT/ITEM: 200				
7	05010	UPPER VALVE PLATE GASKET	1	Pc
16	04084	CYLINDER COVER	1	Pc
17	06828	HEXAGON HEAD SCREW M10X75	8	Pc
18	06820	HEXAGON HEAD SCREW M10X65	2	Pc
19	06644	CYLINDER SCREW M10X60	2	Pc
20	05082	VALVE FLANGE GASKET	2	Pc
21	07373	SHUT-OFF VALVE	1	Pc
22	05846	HEX. HAED SCREW M10X30	2	Pc
23	05514	LOCKING SCREW 1/8" NPTF	4	Pc
24	05301	SLEEVE-PRESSURE BALANCE	2	Pc
25	04481	CONNECTING ROD 90 LONG	2	Pc
ONLY AVAIL.AS COM.AS.KIT/ITEM: 210				
26	05516	CONNECTING ROD SCREW M6X30	4	Pc
28	07111	PISTON ø55 OPTIMIZED	2	Pc
ONLY AVAIL.AS COM.AS.KIT/ITEM: 203				
29	07212	PISTON PIN ø15X10X46	2	Pc
30	05551	SEEGER CIRCLIP 15X1	4	Pc
31	05390	OIL CONTROL RING PISTON 55	2	Pc
32	05380	TAPERED COMPR.RING PISTON 55	2	Pc
33	03370	FILTER SUCTION SIDE	1	Pc
34	07373	SHUT-OFF VALVE	1	Pc
35	05846	HEX. HAED SCREW M10X30	2	Pc
38	05056	REAR BEARING FLANGE GASKET	2	Pc
39	04129	REAR BEARING FLANGE	1	Pc
ONLY AVAIL.AS COM.AS.KIT/ITEM: 211				
40	05565	STEEL BALL ø5,56	4	Pc
41	04380	PUMP-CASING	1	Pc
42	05327	SET GEAR WHEEL OIL-PUMP	1	Pc
44	05330	PUMP PLATE, CPL.	1	Pc
45	05077	COVER PLATE GASKET	1	Pc
46	04164	COVER PLATE	1	Pc
47	05423	HEX. HEAD SCREW M8X30	8	Pc
48	04435	OIL FILTER CPL.	1	Pc
49	06763	HEXAGON HEAD SCREW M5x8	1	Pc
50	06762	DISC ø5,3x25x1,25	1	Pc
51	05153	O-RING ø34,59X2,62	1	Pc
52	06001	SIGHT GLASS ø62	1	Pc
ONLY AVAIL.AS COM.AS.KIT/ITEM:				

Spare parts list valid for the following types:

No longer

<Version ID>

series since:

COMPR. - F3

Item no. : 12015<001>

COMPR. - FX3

Item no. : 12085<001>

Pos.	Part no.	Description	Quantity	QU
		208		
55	05402	HEX. HEAD SCREW M6X16	4	Pc
56	07221	CRANKSHAFT 49 STROKE ONLY AVAIL.AS COM.AS.KIT/ITEM: 205	1	Pc
57	05373	BEARING BUSH ø34Xø30X25 ONLY AVAIL.AS COM.AS.KIT/ITEM: 212	1	Pc
58	04139	FRONT BEARING FLANGE ONLY AVAIL.AS COM.AS.KIT/ITEM: 212	1	Pc
59	05419	HEX. HEAD SCREW M8X20	8	Pc
61	05186	PRESSURE SPRING-SHAFT SEAL ONLY AVAIL.AS COM.AS.KIT/ITEM: 201	1	Pc
62	05289	RING GUIDE-SHAFT SEAL COVER ONLY AVAIL.AS COM.AS.KIT/ITEM: 201	1	Pc
63	05157	O-RING ø25X3,53 ONLY AVAIL.AS COM.AS.KIT/ITEM: 201	1	Pc
64	05139	RING SLIP ONLY AVAIL.AS COM.AS.KIT/ITEM: 201	1	Pc
65	05062	SHAFT SEAL COVER GASKET	1	Pc
66	04306	SHAFT SEAL COVER ONLY AVAIL.AS COM.AS.KIT/ITEM: 201	1	Pc
67	05401	HEX. HEAD SCREW M5X20	6	Pc
68	05671	WOODRUFF KEY A4X6,5	1	Pc
69	05659	DISC ø24X8,4X3	1	Pc
70	05663	SPRING WASHER A8	1	Pc
71	05421	HEX. HEAD SCREW M8X25	1	Pc
73	06400	LOCKING SCREW M22X1,5	1	Pc
74	05342	SEAL RING 27X22X2	1	Pc
78	05789	CAP NUT UNF 7/16"	4	Pc
79	05809	CAP NUT 3/4" UNF.	2	Pc
80	05807	SEAL RING 25,4X22,2X1,5(±0,2)	2	Pc
83	05803	SOLDERED CONN. 1 1/4"X22	1	Pc
84	05804	SOLDERED CONN. 1 1/4"X28	1	Pc
89	05321	GEAR WHEEL OIL-PUMP DRIVEN ONLY AVAIL.AS COM.AS.KIT/ITEM: 202	1	Pc
90	05325	GEAR WHEEL OIL-PUMP DRIVEN ONLY AVAIL.AS COM.AS.KIT/ITEM: 202	1	Pc
92	05083	VALVE FLANGE GASKET	1	Pc
93	05618	PROTECTIVE PLUG ø22,5	1	Pc

Spare parts list valid for the following types:

No longer

<Version ID>

series since:

COMPR. - F3

Item no. : 12015<001>

COMPR. - FX3

Item no. : 12085<001>

Pos.	Part no.	Description	Quantity	QU
94	05619	PROTECTIVE PLUG ø28,8	1	Pc
95	06256	NAMEPLATE,UNPRINTED 35x61 MM	1	Pc
152	09932	LABEL "IMPORT.INSTRUCT." TO ATTACH TO THE OIL PUMP NOT SHOWN IN EXPLODED VIEW	1	Pc
153	03901	GASKET SET NOT SHOWN NICHT EINZELN LIEFERBAR	1	Pc
198	09702	OPERATING INSTRUCTIONS F1-16 INDIVIDUALLY ADDED ----- ASSEMBLY KITS -----	1	Pc
200	08198	SET VALVE PLATE	1	Pc
201	08001	SET SHAFT SEAL	1	Pc
202	08043	SET OIL PUMP	1	Pc
203	80103	SET PISTON ø55 (OPTIMIZED)	2	Pc
204	08022	SET PISTON-CONNECTING ROD	2	Pc
205	08054	SET CRANKSHAFT	1	Pc
206	08088	SET SHUT-OFF VALVE NW20	1	Pc
207	08091	SET SHUT-OFF VALVE NW25	1	Pc
208	08130	SET SIGHT GLASS ø62	1	Pc
209	08070	SET GASKETS NOT SHOWN	1	Pc
210	08304	SET CONNECTING ROD	2	Pc
211	08155	SET REAR BEARING	1	Pc
212	08153	SET FRONT BEARING ----- ACCESSORIES ----- (NOT SHOWN)	1	Pc
313	08131	SET START UNLOADER 220-240V	1	Pc
314	08143	SET W-CYLINDER COVER	1	Pc
315	08424	SET OIL S.HEAT.60W 220-240V	1	Pc
330	04186	FLYWHEEL ø210 SHOWN IN EXPLODED VIEW	1	Pc
3999	02279	MACH.OIL SP46 / 1 LTR. CAN	1	Pc
3999	02280	MACH.OIL SP46 / 5 LTR. CAN	1	Pc
3999	02281	MACH.OIL SP46 /20 LTR. CAN NOT SHOWN ONLY FOR R22-COMPRESSORS!	1	Pc
3999	02282	MACH.OIL SE55 / 1 LTR. CAN	1	Pc
3999	02283	MACH.OIL SE55 / 5 LTR. CAN	1	Pc
3999	02284	MACH.OIL SE55 /10 LTR. CAN NOT SHOWN ONLY FOR X-COMPRESSORS!	1	Pc